



CONTROLPRES

DEVICE FOR CONTROL AND PROTECTION OF THE PUMP

Can be energized with either 115 Vac or 230 Vac.

Starts and stops the pump depending on opening and closing of the taps.

It allows to reduce the maximum pressure of the pump and to set the working pressure.

Stops the pump in case of a water shortage and protects it from dry running.

Is equipped with automatic restart in case of failure and anti-jamming function.

No need for an expansion tank, check valve, filter or fittings.

Can be installed on surface and submersible pumps up to 3 HP.





Maintenance free.

MODELS AND TECHNICAL FEATURES

	CONTROLPRES
Single-phase mains voltage	115/230 Vac
Acceptable voltage fluctuation	+/- 10%
Frequency	50/60 Hz
Current max.	16 A
Power max. at 115V	1,1 kW (1,5 HP)
Power max. at 230V	2,2 kW (3 HP)
Protection degree	IP 65
Operating pressure max.	12 bar
Operating temperature max.	65 °C
Minimum flow	~1 l/min
Pressure regulating range	3 - 6,5 bar
Male connections	Gc 1"1/4
Certifications	TÜV SÜD

CONTROL PANEL

SIGNALING OF THE WORKING PHASES AND ANOMALIES

	POWER ON	Green led on	Device energized
	PUMP ON	Yellow led on	Pump running
	FAILURE	Red led on	Water shortage
	RESTART	Button	Reset after failure

INSTALLATION AND STARTUP

The device can be installed directly on the pump or between the pump and the first tap. Make all the electrical connections, check that the pump is correctly primed, open a tap and energize. From now on, the device will turn the pump on and off depending on the opening and closing of the tap. In case of water shortage, the device will stop the pump and protect it from dry running [red "Failure" led blinking]. In case of a temporary blackout, the device will automatically rearm once the electricity returns.



REGULATION OF THE WORKING PRESSURE

To set the pressure to the desired value, turn the knob on the rear of the device clockwise to increase the pressure and counterclockwise to decrease it [adjustment range from 3 to 6.5 bar]. The restart value is directly proportional to the regulated pressure [see table].

SET PRESSURE	3 bar	3,5 bar	4 bar	4,5 bar	5 bar	5,5 bar	6 bar	6,5 bar
RESTART PRESSURE	1,2 bar	1,5 bar	2 bar	2,5 bar	3 bar	3,5 bar	4 bar	4,5 bar
FLOORS NUMBER	4	5	6	8	10	11	13	15
BUILDING HEIGHT (H)	12 mt	15 mt	20 mt	25 mt	30 mt	35 mt	40 mt	4,5 mt
MAX PUMP PRESSURE	min 4,5 bar	min 5 bar	min 5,5 bar	min 6 bar	min 6,5 bar	min 7 bar	min 7,5 bar	min 8 bar

AUTOMATIC RESTART AND ANTI-JAMMING FUNCTION

In case of stopping due to a water shortage, the device will automatically make 10 double attempts to rearm over the 24 hours following the failure, each lasting approximately 5 seconds to allow the pump and the system to reload if possible. The user can try to rearm the device at any time by pressing the Restart button. If for any reason the pump remains idle for 24 consecutive hours, the device will start the pump for about 5 seconds.